

# DIP SWITCH SETTINGS

9205/9305

DEFAULT  
OFF ON



1 - DC SERVO

OFF

ON

— Enable DC Servo

2 - OPERATION MODE CV/CC

CC

CV

— Controlled-voltage or controlled-current operation

3 - COMPENSATION NETWORK 2

OFF

ON

— Compensation network #2 (for controlled-current operation)

4 - COMPENSATION NETWORK 1

OFF

ON

— Compensation network #1 (for controlled-current operation)

5 - CONTROL CONFIGURATION LEADER/FOLLOWER

FOLLOWER

LEADER

— Configuration as Leader or Follower for bridge connection

6 - COUPLING DC/AC

AC

DC

— DC enable or DC block

7 - GAIN BIT 3 (MSB)

OFF

10

Gain selection (2.5 to 20)

8 - GAIN BIT 2

OFF

5

9 - GAIN BIT 1 (LSB)

OFF

2.5

ALL OFF = 2.5  
ALL ON = 20

10 - ELECTRONIC GAIN MATCHING

OFF

ON

— For factory configuration only

11 - CURRENT LIMIT BIT 1

OFF

+30A

Current Limit (15A to 60A)

12 - CURRENT LIMIT BIT 2

OFF

+15A

BOTH OFF = 15A  
BOTH ON = 60A

NOTE: ALL BIT SWITCHES ARE ADDITIVE. RIGHT = ON.

**RED = FACTORY DEFAULT**